



Trekstore surftab breeze 7.0 plus Vetro touchscreen Replacement

Follow the guide to replace glass or other parts after opening the device


Written By: Smilzo



INTRODUCTION

Follow the guide to replace glass or other parts after opening the device

Step 1 — touchscreen glass



- With a thin tool to remove the back cover by prying between the screen and cover along the entire perimeter of the device

Step 2



- Talking to other attention fixed on the back cover with 2 screws
- Unscrew the screws and remove the speaker cover

Step 3




- with the help of a hair dryer or heat warm the edges of the glass, and with a fine instrument to remove the glass by pulling the adhesive

Step 4



- lift the protective film touchscreen connector
- Push the 2 blacks hooks to free the flat from the connector

Step 5



- remove and replace with the new touchscreen

Per rimontare il dispositivo, segui queste istruzioni in ordine inverso.

This document was last generated on 2017-06-17 07:30:54 PM.